


User Manual

Indoor / Outdoor Thermometer

Features

- Indoor / outdoor measuring range : -58°F to 158°F, -50°C to 70°C.
- Two-line display shows both indoor and outdoor temperature.
- Maximum and minimum recording for both indoor and outdoor temperature.
- 3 second delay back light.
- 1 “AAA” size battery included.
- 10 ft. submersible probe.



Buttons

1. **MAX/MIN** button
2. **CLEAR** button
3. **°C / °F** button
4. **LIGHT** button

Default Settings

When the battery is installed the following settings will be displayed:
Indoor and outdoor temperature display format is Fahrenheit
Maximum and minimum records for temperatures are reset

Operating Instructions

1. Pressing the **MAX/MIN** button will cycle between the maximum record, minimum record and current temperature for indoor and outdoor.
2. Pressing the **CLEAR** button in minimum or maximum record display mode will reset the maximum and minimum records to the current temperature.
3. Pressing the **°C / °F** button will toggle between temperature display formats.
4. Pressing the **LIGHT** button will turn on the back light for 3 seconds.

Temperature Sampling

The sampling time for indoor and outdoor temperature measurement is 30 seconds.

Reset Operation

Should an error occur in the temperature reading or if you wish to reset the unit, inserting a paper clip or thin wire into the opening on the back of the case marked RE will reset all readings to the Default Settings.

Placement

This unit can be wall mounted using the built-in hanger or can be placed on a desk or table using the built-in stand. When selecting a location for the base unit be sure it is near enough to a window or door so the wired sensor can reach outside. The sensor has an adhesive pad for easy attachment. Remove the protective paper covering and press firmly. For accurate readings please select a sheltered location out of direct sunlight.

LIMITED WARRANTY INTERNATIONAL

Consumer may have more remedies at law than follows. Chaney Instrument Company warrants to the owner, this product to be free from defect in material and workmanship for one year from date of purchase. CHANEY INSTRUMENT SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER ARISING IN CONTRACT OR TORT. Chaney Instrument's obligation (at its option) is limited to repair or replace this product.

For in- warranty repair, send thermometer, accompanied by Guarantee, bearing Dealer's name and date of purchase, with \$5.00 to cover handling and postage, to:

Chaney Instrument Company
965 Wells Street
Lake Geneva, Wisconsin 53147

ACURITE®

Lake Geneva, WISCONSIN 53147

www.chaneyinstrument.com