ACU·RITE®

| 00884 | **Digital Thermometer with Probe** |

Measures indoor & outdoor temperature
MIN/MAX temperature readout with memory
Wide temperature range -58˚F to 158˚F
Folding stand or wall mount
10' Weather-proof sensor wire

INSTALLATION INSTRUCTIONS:
The unit: Choose a suitable space away from direct sunlight, heating and air conditioning vents.
Option 1: Install wall mount bracket with enclosed 2 screws or double sided tape.
              Hang unit on mounted bracket.
Option 2: Use flip-down stand to display on flat surface.

The outside sensor:
Make sure that the remote sensor wire will reach outside before mounting the unit. Remove the protective paper from sensor, press firmly in position free from direct sunlight and heavy saturation. For Auto: an ideal position is behind the front bumper, not directly in the wind stream. Avoid engine or radiator heat.

Normal display shows inside and outside temperature in 1/10 degree.

MIN MAX MEMORY
Press the MIN MAX MEMORY button once, maximum and miminum indoor temperature will be shown. Press the MIN MAX MEMORY button twice, maximum and miminum outdoor temperature will be shown. The display willl show normal temperature if the button is pushed a third time, or if after 8 seconds, no button is pushed. To delete all stored MIN MAX MEMORY records, push the CLEAR button. New memory can be recorded instantly when display turns back to normal temperature mode.

CHANEY INSTRUMENT CO.
LAKE GENEVA, WI 53147
www.chaneyinstrument.com