

00720 00723

Candy, Jelly & Deep Fry Thermometer

Safety Cap Easy Grasp Red Ball Adjustable Clip

INSTRUCTIONS FOR USE:

Clip to side of pan. Place tip of thermometer at least 2-1/2" into liquid. Do not let tip touch bottom or sides of pan. Follow temperature instructions of your favorite recipe.

DEEP FAT FRYING:

Heat fat to desired temperature. Lower food into fat. Temperature may temporarily drop. Cook food for time specified.

WARNING:

DO NOT wipe or handle hot thermometer with wet cloth.

DO NOT lay hot thermometer on cold or wet surface. DO NOT heat beyond \Box thermometers temperature capacity or tube may break. DO NOT use in oven.

CANDY/DEEP FRYING GUIDELINES

; ;	Soft-ball stage234°to 240°F	(118°to 120°C) (121°to 130°C) (132°to 143°C)
)]]	Jelly	(104°C) (177°C) (177°to 191°C) (177°to 191°C) (191°to 196°C) (196°to 202°C)

For answers to your food safety questions call: 1-800-535-4555
USDA's Meat and Poultry Hotline



CHANEY INSTRUMENT CO.

LAKE GENEVA, WI 53147

www.chaneyinstrument.com

LIMITED WARRANTY

Any Chaney instrument which proves to be defective in material or workmanship within one year of original purchase will be repaired or replaced. This warranty does not cover damage in shipment or failure caused by tampering, carelessness or abuse.