


TIME ZONE MAP



TIME ZONE

- AST: Atlantic
- EST: Eastern
- CST: Central
- MST: Mountain
- PST: Pacific
- AKST: Alaska
- HAST: Hawaii-Aleutian

Do not return product to retail store.

For Technical Assistance and product return information, please call Chaney Instrument Co. direct at: 877-221-1252

LIMITED WARRANTY – INTERNATIONAL

Consumer may have more remedies at law than follows. Chaney Instrument Company warrants to the owner, this product to be free from defect in material and workmanship for one year from date of purchase. CHANEY INSTRUMENT SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER ARISING IN CONTRACT OR TORT. Chaney Instrument's obligation (at its option) is limited to repair or replace this product. For in-warranty repair, send clock, accompanied by Guarantee, bearing Dealer's name and date of purchase, with \$5.00 to cover handling and postage, to:

www.chaneyinstrument.com
Tel: 877-221-1252
Made in China

Chaney Instrument Company
965 Wells Street
Lake Geneva, Wisconsin 53147



"SNOOZE / LIGHT" BUTTON ON BACK

FEATURES:

- Automatically displays the correct time once powered on, all you need to do is select your time zone and Daylight Saving Time (DST) preferences.
- Automatically resets twice a year for Daylight Saving Time (DST).
- 2 x "AA" alkaline batteries included
- Daily Alarm
- Temperature display
- Month and day display
- Year display

Setup:

For initial setup of your new alarm clock, just pull the clear insulating strip out to activate the batteries (see figure 1) It will automatically display the current time in Atlantic time. Next, select your desired time zone and daylight saving time preferences.

Setting The Time Zone and Daylight Saving Time (DST):

1. Push the "TIME ZONE" button to switch time zones to the desired time zone. The currently selected time zone will be indicated on the main display. For more information on time zones, refer to page 4 of this manual.
2. Next, press the "DST SET" button to turn the auto DST feature on or off.
3. You must also determine which DST setting to use: old, new or off
Due to possible future changes in the DST, this unit is equipped with a selection switch to choose between the traditional DST setting (OLD) or the new proposed DST time change dates. Refer to page 3 of this manual for more information about the different DST settings.

Setting the Alarm Time

1. Press the "ALARM SET" button until the HOUR display begins to blink.
 2. Press the "-" or "+" buttons until the desired HOUR is reached (note the "PM" indicator).
- NOTE: Fast setting mode can be activated by pressing and holding the "-" or "+" buttons for 5 seconds.**
3. Press the "ALARM SET" button once to confirm hour setting and move on to minute setting.
 4. Press the "-" or "+" buttons until the desired MINUTE is reached.
 5. Press the "ALARM SET" button once again to EXIT the alarm set mode. The alarm icon will now show, indicating that the alarm will now sound at the preset alarm time.

Alarm Settings

To turn the alarm function on, push the "ALARM SET" button. A small alarm clock indicator icon will appear on the display when the alarm function is switched to the "ON" position. To turn OFF the alarm function completely, push the "ALARM SET" button until the alarm clock indicator icon is no longer visible on the main display.

Snooze/Backlight:

The display may be illuminated at any time by pressing the "SNOOZE/LIGHT" button on the back of the unit. The "SNOOZE/LIGHT" button also activates the 8 minute snooze alarm () when the alarm sounds. You may press the "SNOOZE" bar up to four times, after the fourth time the alarm will reset itself and will not sound again until the next day.


Low Battery Indicator:

When the main batteries run low, the battery icon will flash.

Display Modes:

There are several different display modes that can be chosen. The time will always be displayed, but other information display areas can be customized. You may alternate between °C and °F temperature display mode by pressing the "°C/°F" button. You may also choose to display the Year or Date by pressing the "YEAR/DATE" button.

Figure 1



BOTTOM OF UNIT

Manual Time Set:

If you would like to set your alarm clock a little ahead, or if the unit ever loses time for any reason, the clock can be set manually by following these instructions.

1. Press and hold the "DST SET" button for 2 sec. to enter the manual time set mode.
2. The year will be flashing, adjust up or down using the "+" or "-" buttons.
3. Press the "DST SET" button once to move on to the month setting mode.
4. The month will be flashing, adjust up or down using the "+" or "-" buttons.
5. Press the "DST SET" button once to move on to the hour setting mode.
6. The hour will be flashing, adjust up or down using the "+" or "-" buttons. Note the PM indicator on the display.
7. Press the "DST SET" button once to move on to the minute setting mode.
8. The minutes will be flashing, adjust up or down using the "+" or "-" buttons.
9. Press the "DST SET" button again to exit the manual set mode.

MORE INFORMATION ON DAYLIGHT SAVING TIME (DST):

The following chart illustrates the differences between the auto DST settings and when each setting automatically changes the time during the year.

| NEW DST ON | DST ON | DST OFF |
|---|--|----------------|
| 2007 and beyond: 2:00 am 2nd Sunday in March 2:00 am 1st Sunday in November | 2006: 2:00 am 1st Sunday in April 2:00 am last Sunday in October | No DST changes |

AUTO DST NOTE: portions of Indiana and Arizona do not observe daylight savings time. If you live in an area that does not observe daylight saving time, turn the DST function off.